



Watch GPS Instruction Manual

If you have any other questions or concerns,
please call 1-800-777-7899 or go to www.IZZO.com.

TABLE OF CONTENTS

1. General Description of Hardware	2
1.1 Basic Specifications	2
1.2 Accessories List	2
1.3 Screen Display Description	3
2. Getting Started	4
2.1 Power On/Off	4
3. Time Mode	4
4. Using Swami on the Course	5
4.1 Getting Started	5-6
4.2 Play Mode	7
4.4 Shot Distance	7
4.3 Electronic Score Card	8
4.3 Odometer	9
4.5 Editing Green Location	9-10
4.3 End Round	10
5. Swami Settings	11
5.1 Alarm	11
5.2 Time Format	11
5.3 Time	12
5.4 Daylight Saving Time	12
5.6 Date Format	13
5.6 Date	13
5.7 Language	13
5.8 Unit	14

5.9 Backlight	14
5.10 Sound	14
5.11 Display Type	15
Charging Swami	15
Caution	16
Using Conditions	16
Warranty	17
Questions & Answers	17
Registration Card	18

1. General Description of Hardware

1.1 Basic Specifications

Number of courses stored	+25,000 Worldwide
Receiving chip	SiRF Star III
Battery	300 mAh coin type rechargeable
Battery Life	Golf Mode – 6.5 hours / Time Mode – 40 days
USB interface	Supported
Display size	1.26" Transflective 144x168 pixels
Water resistant	Yes IPX7

1.2 Accessories List

- USB Cable
- Charging Station
- AC charging adapter
- User Manual

1.3 Screen Display Description



Key Description:

- **Power/Backlight:** Press and hold (3 seconds) to turn the device on and off. Press to turn on backlight.
- **OK/Menu:** Press to select menu options and acknowledge messages. Press to switch pages (**Green View**, **Shot Distance**, **Scorecard**, and **Odometer**) Press and hold to open **Main Menu**.
- **Up:** Press to scroll up through menus, holes, and settings.
- **Down:** Press to scroll down through menus, holes, and settings.

2. Getting Started

2.1 Power On/Off



1. Press and hold **[Power/Backlight]** key for 3 seconds until the power is on.
2. The device will show the Start-Up logo first and into the **Time Mode** screen.
3. To turn off the device, press and hold the **[Power/Backlight]** key.

3. Time Mode




- A. Info Bar
- B. 2nd Row - Time/Day
- C. 3rd Row - Date

1. From **Time Mode** page, press **[Up]** key to change 3rd row to display 2nd **Time Zone**.
2. Press **[Up]** key again to change 3rd row to display **Sunrise** time.
3. Press **[Up]** key again to change 3rd row to display **Sunset** time.
4. Press **[Up]** key again to change 3rd row to display **Seconds**.
5. Press **[Up]** key again to change 3rd row to display **Stopwatch**.
6. To start **Stopwatch**, press **[OK/Menu]** key
7. To pause **Stopwatch**, press **[OK/Menu]** key again.
8. To reset the **Stopwatch**, press and hold **[Down]** key.


4. Using Swami on the Course (directions on page 6)

1



Time Mode Page

2



Main Menu Page


3



4



5



6




4. Using Swami on the Course (Screen shots on page 5)

4.1 Getting Started

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu** page.
2. Use **[Up]** or **[Down]** key to select **Play Golf** and press **[OK/Menu]** key.
3. Device will begin to search for satellite signal, you can press **[OK/Menu]** key to cancel request. *(Note: When Swami is used for the first time or has not been used for a while, it may take a few minutes to locate satellites. If it has not located them within 5 minutes, please turn watch completely off and try again).*
4. When device has found the satellite, it will show a **Ready** icon, press the **[OK/Menu]** key to continue.
5. The device will begin auto searching the surrounding courses that the device supports, you can press **[OK/Menu]** key to cancel request.
6. It will then list the nearest golf courses to choose from. Use **[Up]** or **[Down]** key to select the golf course, then press **[OK/Menu]** key to continue.
7. Device will begin **Play Mode** and start at hole #1, user can press **[Up]** or **[Down]** key to switch the hole number. *(see page 7 for Play Mode screen)*

4.2 Play Mode




4.3 Shot Distance




1. From **Green View** page, press **[OK/Menu]** key to switch to **Shot Distance** page.
2. Press **[Down]** key to reset distance to 0.
3. Press **[Up]** key to start marking.
4. Press **[Up]** key again to pause marking.
5. Press **[Down]** key to reset when finished.
6. Press **[OK/Menu]** key twice to return to **Play Mode** screen.

4.4 Electronic Scorecard




1. From **Shot Distance** screen, press **[OK/Menu]** key to switch to **Scorecard** screen.
2. Use **[Up]** or **[Down]** key to see scorecard for each hole.
3. To change the default par press and hold **[Down]** key to access **Edit** mode. Use **[Up]** or **[Down]** key to change the par then press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to enter user score and press **[OK/Menu]** key.
5. To enter user score use **[Up]** or **[Down]** key to enter score and press **[OK/Menu]** key
6. To exit **Edit** mode, press and hold **[Up]** Key.
7. Score for the round will then update at the bottom of the screen.
8. Press **[OK/Menu]** key to return to **Play Mode** screen.

4.5 Odometer




1. From **Time Mode** or **Play Mode**, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Odometer** and press **[OK/Menu]** key.
3. Press **[Up]** key to start **Odometer**. *(Note: Will beep three times when ready)*
4. Press **[Up]** key again to pause **Odometer**.
5. Press **[Down]** key to reset **Odometer**.
6. To exit **Odometer**, press and hold **[OK/Menu]** key to return back to **Main Menu**.
7. Press and hold **[OK/Menu]** key again will return back to **Time Mode** page.

4.6 Editing Front, Center & Back Green Locations



1. From **Play Mode** page, press and hold **[Down]** key to access **Edit** mode.
2. Use **[Up]** or **[Down]** key to select **Back / Center / Front**. *(Note: Yardage for Front, Center or Back will blink when selected).*
3. Next, stand with Swami Watch at the point of new green location. *(Example: If you are editing the back of the green, stand with the Swami Watch at the point you wish to mark as the new back of the green).*

4.6 Editing Front, Center & Back Green Locations (continued)



4. Press **[OK/Menu]** key to remark. The new location where the GPS unit is located should read "0" yards.
(Example: If you edited the back of the green, you are now standing 0 yards between you and the back of the green).
This change will be saved on your Swami Watch for future use.
5. Press and hold **[Up]** key to exit **Remark** mode.

4.7 End Round

1. Press and hold **[OK/Menu]** key to return back to **Main Menu** will end the golf round.
2. Press and hold **[OK/Menu]** key again to return back to **Time Mode** page.

5. Swami Settings

5.1 Alarm

Alarm
Time Format
Time
Daylight
Date Format

1. From *Time Mode* page, press and hold **[OK/Menu]** key to access *Main Menu*.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Alarm** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **Alarm 1/Alarm 2/Alarm 3** and press **[OK/Menu]** key.
5. Use **[Up]** or **[Down]** key to set **HH (00 ~ 23)** and press **[OK/Menu]** key.
6. Use **[Up]** or **[Down]** key to set **MM (00 ~ 59)** and press **[OK/Menu]** key.
7. Use **[Up]** or **[Down]** key to set **On/Off** and press **[OK/Menu]** key.
8. Press and hold **[OK/Menu]** key to return back to *Settings Menu*.

5.2 Time Format

1. From *Time Mode* page, press and hold **[OK/Menu]** key to access *Main Menu*.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Time Format** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to set **12H/24H** and press **[OK/Menu]** key.
5. Press and hold **[OK/Menu]** key to return back to *Settings Menu*.

5.3 Time

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Time** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **Time 1/Time 2** and press **[OK/Menu]** key.
5. Use **[Up]** or **[Down]** key to set **Auto** or **Manual** and press **<OK/Menu>** key.
6. If selecting **Auto**, you must be outdoors initially for this option to work properly. The watch must be able to receive a satellite signal in order to set the current time. After the time is set, it will keep that time wherever you go.
7. If selecting **Manual**, use **[Up]** or **[Down]** key to set **HH (00 ~ 23)** and press **[OK/Menu]** key.
8. Use **[Up]** or **[Down]** key to set **MM (00 ~ 59)** and press **[OK/Menu]** key.
9. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

5.4 Daylight Saving Time

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Daylight** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **On/Off** and press **[OK/Menu]** key
On = current time minus 1 hour.
5. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

5.5 Date Format

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Date Format** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** keys to change date format between **DD-MM-YY** (*Day/Month/Year*), **MM-DD-YY** (*Month/Day/Year*) and **YY-MM-DD** (*Year/Month/Day*).
5. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

5.6 Date

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Date** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **Year** and press **[OK/Menu]** key.
5. Use **[Up]** or **[Down]** key to select **Month** and press **[OK/Menu]** key.
6. Use **[Up]** or **[Down]** key to select **Day** and press **[OK/Menu]** key.
7. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

5.7 Language

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select desired **Language** and press **[OK/Menu]** key.
4. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

5.8 Unit - Change unit of measurement between yards and meters

1. From *Time Mode* page, press and hold **[OK/Menu]** key to access *Main Menu*.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Unit** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **Metric/Imperial** and press **[OK/Menu]** key.
5. Press and hold **[OK/Menu]** key to return back to *Settings Menu*.

5.9 Backlight

6. From *Time Mode* page, press and hold **[OK/Menu]** key to access *Main Menu*.
7. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
8. Use **[Up]** or **[Down]** key to select **Backlight** and press **[OK/Menu]** key.
9. Use **[Up]** or **[Down]** key to select **Off/5s/10s/30s** and press **[OK/Menu]** key.
10. Press and hold **[OK/Menu]** key to return back to *Settings Menu*.

5.10 Sound - Turn button sound On/Off

1. From *Time Mode* page, press and hold **[OK/Menu]** key to access *Main Menu*.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Sound** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **On/Off** and press **[OK/Menu]** key.
5. Press and hold **[OK/Menu]** key to return back to *Settings Menu*.

5.11 Display Type - Invert screen colors between black and clear background

1. From **Time Mode** page, press and hold **[OK/Menu]** key to access **Main Menu**.
2. Use **[Up]** or **[Down]** key to select **Settings** and press **[OK/Menu]** key.
3. Use **[Up]** or **[Down]** key to select **Display Type** and press **[OK/Menu]** key.
4. Use **[Up]** or **[Down]** key to select **Type 1/Type 2** and press **[OK/Menu]** key.
5. Press and hold **[OK/Menu]** key to return back to **Settings Menu**.

CAUTION

Global Position System (GPS) was developed and is managed by United States Department of Defense (DOD) that is responsible for its normal operation and position precision control; the U.S. is entitled to affect function or position precision of the whole system without prior notification or announcement based on its political considerations or safety of national defense.

In order to use SWAMI Watch correctly and safely, you must be aware of some specific knowledge; please read the following attentions in the manual prior to operating the device:


- SWAMI Watch was only designed for the purpose of leisure and recreation and it isn't applicable for industrial or special measurement.
- SWAMI Watch is only an auxiliary device, so we will not take any legal liability of accidents due to mistaken operation or wrong judgment by using SWAMI Watch for measurement.

Using Conditions

As Swami Watch uses GPS, the GPS features are available only in the places that can receive satellite signals, excluding places indoor or in water.

Charging Swami Watch

1. Place Swami Watch on charging station, make sure when docking the unit the black arrow highlight in red on the charging station below (*Image A*) is pointing up toward the buckle of the watch. Unit should rest in slot of charging station. (*Reference Image B*)
2. Plug charging station AC adapter into outlet. Next, press the left side button in toward the watch until it locks into place. (*Reference Image B*). To release watch from charging station press button in top right corner of charging station highlight in red (*Image B*).
3. Swami Watch has begun charging when the screen below (*Image C*) is shown. The 3 bars located in the battery icon will blink when charging. When fully charged, the battery bars will stop blinking. Full charge takes about 4-5 hours.



Warranty / Return Policy

SWAMI is warranted to be free from defects for up to 90 days from your purchase date. Software updates are free of charge. Izzo cannot refund your purchase. Izzo will replace any defective unit within the warranty period. Please call Swami Support at 800-777-7899 to request a Return Authorization. All defective product must be returned to:

Izzo Golf

**1635 Commons Parkway
Macedon, NY 14502**

Please include a note with your Name, Address, Phone # and the Return Authorization #. Your replacement SWAMI will be shipped once we receive and diagnose the returned unit.

QUESTIONS & ANSWERS

Situations	Possible Problems	Solutions
The device cannot be started	A. Battery voltage is too low. B. You didn't press and hold the [Power/Backlight] key for 3 seconds.	A. Charge the battery. B. Press and hold the [Power/Backlight] key until the power is on.
The device cannot detect satellites	A. Time for accessing satellite signal is not enough. B. The device is being started indoors.	A. Turn the Swami Watch off and restart it, then try again. B. Keep the device in an open space without building shelter.



REGISTER YOUR SWAMI WATCH

FILL OUT THE INFORMATION BELOW OR GO TO
WWW.IZZO.COM/SWAMIREGISTRATION

NAME: _____

ADDRESS: _____

EMAIL: _____

PHONE: () _____

DATE PURCHASED: _____ / _____ / _____





**MAIL TO: IZZO GOLF
1635 COMMONS PKWY
MACEDON, NY 14502-9191**

[PLEASE PLACE INSIDE ENVELOPE]

